



WHAT'S NEEDED BEFORE INSTALLATION

- Screwdriver
- Wrench
- Use four #10 screws (ensure they are the appropriate type for the material you are attaching the bird repeller to, and verify that the screw heads are larger than $\frac{1}{4}$).

HOW TO INSTALL

1. Remove the base and top fan from the box, and remove the bolt from the top of the base.
2. Align the curved side of the top fan with the curved side of the base neck, ensuring they fit together properly. Once aligned, insert the provided bolt through the designated hole to secure the connection.
3. Position the top fan at the desired angle.
4. Tighten the bolt with a wrench to secure the fan in the chosen position and insert the bottom nut.
5. For best results, use in areas with high wind and plenty of sunlight.
6. Secure the base to the installation surface by inserting four #10 screws into the designated holes and tightening them firmly.

NOTE

- For optimal installation, it is recommended to use screws rather than adhesive to attach the aluminum base.
- Once installed, the bird repeller should spin freely in the breeze, with the reflecting fan catching the sunlight, scaring birds as they fly by.

INSTALLATION VIDEO

